



# QUICKGEL®

.....  
 Quick clarifier for difficult juices  
 .....

## → TECHNICAL DESCRIPTION

**Quickgel®** is an extremely effective and quick clarifier and is the best choice when it is necessary to clear very cloudy juices in a very short time, in order to prepare them to a following filtration or racking.

It enables to obtain bright and softer juices through a quick clarification, with compact deposits with a reduced volume, thanks to the contemporaneous presence of activated bentonite, gelatine and egg albumin in studied proportions.

After the clarification with **Quickgel®**, juices with a turbidity of 50-150 NTU show nephelometric values of 1-2 NTU.

This clarifier takes advantage of the mutual flocculation of the different active components to clarify products with high concentrations in protective colloids and with a high quantity of suspended solids.

## → COMPOSITION AND TECHNICAL CHARACTERISTICS

Activated bentonite, food grade gelatine, egg albumin.

## → DOSAGE

50 - 150 g/hL.

## → INSTRUCTIONS FOR USE

Dissolve the dose of **Quickgel®** in 10 parts of cold water. Immediately add into the mass the so obtained suspension, by pumping over and possibly utilizing Venturi tubes.

## → STORAGE AND PACKAGING

Store in a dry and cool place.

1 kg packs in 15 kg cartons.  
 25 kg net bags.

